The Single Dock with battery charging for Portable Data Terminal (PDT).
The communications with PC are optionally done via RS232 or USB connections.
A USB-host port provides connections with other USB devices.

Installing PDT to Single Dock

⚠ CAUTION:

1. The Single Dock can be used on horizontal surface only;
   it can't be used for wall mount.

2. Use Only the Single Dock adapter (5Vdc/6.5A)for
   DC power input and the PDT adapter (5Vdc/2.6A)
   can not use in the Single Dock.

PDT

Spare Battery Pack

Charging Spare Battery Pack Note:

1. Both PDT internal battery and spare battery pack
   can be charged simultaneously.
2. The charging LED indicator will show the charging
   status of spare battery pack.

Red: Charging
Green: Fully charged

Power Jack

USB Client

USB Host

Charging LED

RS 232

OPTICON