

Methods for disinfection and sterilization

It is recommended to squeeze a cloth soaked in a neutral detergent diluted with water, and then wipe it gently. It is also possible to use disinfectant such as alcohol for disinfection and sterilization. Depending on the disinfectant used, method, area and frequency of use, there is a risk of product deterioration.

Please be aware of the following conditions and risks to the product before use.



Conditions and precautions when wiping with disinfectant

- It is recommended to squeeze a cloth soaked in disinfectant diluted with water and wipe it gently.
- Use necessary hand protection at all times.
- Use a soft cloth or cut cotton when wiping.
- Tissue paper, etc. may contain a dye that causes scratches.
- Do not soak the product in liquid to prevent water droplets from entering the product, or it may cause a malfunction.
- The transparent "reading window" is a delicate part in terms of performance, you can maintain the performance by minimizing the frequency of wiping as much as possible. When wiping, make sure that there are no traces left behind.
- Do not leave disinfectants or liquids on the product fixing screws or cable connection, as they may corrode.
- Do not use strong acidic or alkaline liquids.
- Do not spray disinfectant etc. directly on the product.
- Before cleaning, turn off the power of the device.

